DESOLAN NT

Concentrated microbicide agent for odour and germ elimination for use in perchloroethylene and hydrocarbon solvent

This multi-effect agent creates the basis for hygienic drycleaning under the usual drycleaning conditions. **DESOLAN NT** is recommended for use in perchloroethylene and hydrocarbon solvent.

DESOLAN NT eliminates unpleasant odours often adhering to drycleaned goods and provides the garments with a fresh, neutral odour. In particular, **DESOLAN NT** has proved well for closed circuit system drycleaning machines being frequently confronted with the problem of odours.

Any germs, bacteria or fungi adhering to soiled textiles or brought into the drycleaning bath will be eliminated by **DESOLAN NT** in the drycleaning bath. Transfer of microbes onto other textile goods is hereby avoided.

According to the requirements, **DESOLAN NT** may be added to the drycleaning bath either concentrated or diluted with the drycleaning detergent or prespotting agent.

Application of pure DESOLAN NT

In case of operating according to the 2-bath-method, pure **DESOLAN NT** is added to the second bath. Dosing is possible by means of the dosing device or in combination with the drycleaning detergent.

Application

Basic concentration

1 to 2 ml DESOLAN NT per litre drycleaning bath

Addition

0.2 to 0.5 ml DESOLAN NT per litre drycleaning bath

Application

Basic concentration

1 to 2 ml DESOLAN NT per litre drycleaning bath

Addition

0.2 to 0.5 ml DESOLAN NT per litre drycleaning bath

Application of DESOLAN NT in combination with the drycleaning detergent

DESOLAN NT is also well compatible with our drycleaning detergents **TAIFUN**, **FRANKOTEX** and **NOVACLIN** and proves to be well miscible, too, with other commercial products.

In case of permanent use of **DESOLAN NT**, it is recommendable to mix the product with the drycleaning detergent and to feed this mixture into the drycleaning bath via the automatic dosing device.

According to dosage and effect required, use

50 to 80 ml DESOLAN NT per kg drycleaning detergent.

Use the measuring glass for filling **DESOLAN NT** into the container with the drycleaning detergent and mix both products by strongly shaking the container. The mixture will remain clear and stable so that, in most cases, no re-mixing will be required.



Seitz GmbH Chemische Fabrik Gutenbergstraße 3 D-65830 Kriftel Tel. (06192) 99 48-0 Fax (06192) 99 48 99

The information provided herein is given on an advisory basis which does not imply any liability on our part.